



WALLPAPER

APPLICATION INSTRUCTIONS
(REGULAR WALLPAPER)

**CHOOSE AN STB-APPROVED WALLPAPER PASTE
(PREFERABLY, A READY MIXED PASTE WITH A PVAC CONTENT).**

- **HERNIA TAPETLIM 1870 (RECOMMENDED)**
- **BOSTIK 65 TAPETLIM**
- **CASCO TAPETLIM 3438**
- **KIILTO TAPETLIM**

DIRECTIONS

- **CHECK THAT THE ROLLS** conform to your order, that none of the rolls are damaged, and that all of them have the same production number. Also check the front of the label to see whether the wallpaper should be applied width-wise.
- **THE SURFACE, GLUE AND** wallpaper should be at normal room temperature, about 18 °C.
- The surface should be dry, clean and free from dust and old pieces of wallpaper. Shiny areas should be sand-papered. Painted surfaces should be washed with soda and thoroughly rinsed. Highly absorbent surfaces should be pre-pasted or primed. Priming should be done where there are surfaces with large differences in colour, such as spackled seams on dark surfaces.
- **FOR BEST RESULTS** when hanging dark-coloured wallpaper, the walls should be coated with primer that contains the same colour nuance as the wallpaper.
- **MAKE SURE THAT** the edges are amply pasted, but not so that paste seeps out during hanging. A pasting machine will produce the best results*.
- **FOLD THE WALLPAPER** lengths together, and then roll them out together, allowing them to swell for about five minutes.
- **MAKE SURE NOT TO** make creases, and do not place several pasted lengths on each other.
- **THE LENGTHS SHOULD** be placed edge to edge. Use a wallpaper brush, and smooth the lengths from the middle out to the sides. If, despite precautions, paste has come out on the front of the wallpaper, remove it immediately with clean water and a clean rag. When doing so, make sure to clean and dry the entire length.
- **AFTER HANGING TWO OR** three lengths, check the results for any differences in colour or other defects.
- **GAPS IN THE SEAMS, RAISED** edges, or blisters are not due defects in the wallpaper, but are rather caused by the underlying surface, amount of paste and the hanging itself. N.B. Never close a newly wallpapered room. Instead, air out the room, and keep it at normal room temperature

*A simple and easy-to-use machine that can be rented in well-stocked wallpaper stores (Certain types of wallpaper pastes are especially adapted to pasting machines).

S V E N S K T T E N N