



## TABLE 974

**SIDE TABLE 974 WAS** designed by Josef Frank for Svenskt Tenn in 1938. The table originally had an oval-shaped brass plate within the rectangular pyramid-mahogany top with its rounded corners and high edge. Turned out legs with stylized paw feet and the H-shaped base were typical of Josef Frank's designs.

**DESIGN:** Josef Frank / **HEIGHT:** 55 cm / **LENGTH:** 76 cm / **BREDD:** 56 cm

# TABLE 974

**MATERIAL** Frame of lathed mahogany. Table top in veneer of pyramid mahogany.

**CARE INSTRUCTIONS** Svenskt Tenn's furniture is made from wood and then lacquered. The woodwork should be cleaned simply with a soft cloth dampened with mild dish detergent or soapy water. Make sure to dry it with a soft cloth.

Polish, oil or abrasive cleaners should never be used on the furniture. Never expose the furniture to prolonged humidity or direct heat. If an injury in the paint or wood occurs, you should immediately contact a furniture restorer. Often you can restore easier damage, but the damage is likely to worsen if not taken care of. Never move the furniture by dragging it across the floor.

The furniture lacquer can be damaged by direct heat and lengthy exposure to dampness. Keep in mind that water-filled vases can cause condensation.

Colour variations can occur if parts of the tabletop or other wood surfaces on furniture are covered early on with, for example, books or other items. It is therefore recommended that you not put vases or placemats and the like, on the tabletop for some time when the furniture is new. This will enable the wood to age evenly over a period of time. Avoid exposing your furniture to large changes in temperature and humidity, which can significantly affect natural movements of the wood.

---

HÖJD	55 cm
LÄNGD	76 cm
BREDD	56 cm
ITEM NUMBER	100236