



## COFFEE TABLE 2073

**COFFEE TABLE 2073 WAS DESIGNED** by Josef Frank in 1949. The table was often included in interior design projects for Swedish embassies after the Second World War, hence the nickname the “Diplomat table”.

**DESIGN:** Josef Frank / **HEIGHT:** 48 cm / **LENGTH:** 110 / 105 cm / **WIDTH:** 70 / 105 cm

# COFFEE TABLE 2073

**MATERIAL** Frame in mahogany with a veneered table top in pyramid mahogany.

**CARE INSTRUCTIONS** Svenskt Tenn's furniture is made from wood and then lacquered. The woodwork should be cleaned simply with a soft cloth dampened with mild dish detergent or soapy water. Make sure to dry it with a soft cloth.

Polish, oil or abrasive cleaners should never be used on the furniture. Never expose the furniture to prolonged humidity or direct heat. If an injury in the paint or wood occurs, you should immediately contact a furniture restorer. Often you can restore easier damage, but the damage is likely to worsen if not taken care of. Never move the furniture by dragging it across the floor.

The furniture lacquer can be damaged by direct heat and lengthy exposure to dampness. Keep in mind that water-filled vases can cause condensation.

Colour variations can occur if parts of the tabletop or other wood surfaces on furniture are covered early on with, for example, books or other items. It is therefore recommended that you not put vases or placemats and the like, on the tabletop for some time when the furniture is new. This will enable the wood to age evenly over a period of time. Avoid exposing your furniture to large changes in temperature and humidity, which can significantly affect natural movements of the wood.

---

	SQUARE	RECTANGULER
HEIGHT	48 cm	48 cm
LENGTH	105 cm	110 cm
WIDTH	105 cm	70 cm
ITEM NUMBER	100256	100255