

# CHAIR 2025


DESIGNER: JOSEF FRANK, 1925

Josef Frank felt that a dining room chair should be so light that it can be lifted with only one finger, and that the user should easily be able to move the chair around in the room. He designed this graceful chair in 1925, for his company Haus und Garten in Vienna. In order to create excitement in the design, Josef Frank often chose to mix different kind of woods and materials. So even in this classic chair.

---

ITEM NR RED/BLACK/WHITE:	102292, 102294, 102295
HEIGHT/SEAT HEIGHT:	95 CM/46 CM
DEPTH/SEAT DEPTH:	57 CM/42 CM
WIDTH:	44 CM
FABRIC REQD 130/150 CM/PRINTED:	0,6 M (2 CHAIRS)
FABRIC REQUIRED HORSEHAIR:	0,6 M
FABRIC REQUIRED LEATHER:	6,0 SQFT
MATERIAL:	BIRCH, PLAITED WEBBING, COLD FOAM/POLYETHER & SYNTHETIC BATTING

---



HANDCRAFTED IN SWEDEN

*S V E N S K T T E N N*

## CARE INSTRUCTIONS

Svenskt Tenn's furniture is made from wood that is varnished or coated. Clean with a soft cloth dampened with mild dish detergent or soapy water. Dry with a soft cloth. Do not expose the furniture to prolonged humidity or direct heat or use polish, oil or abrasive cleaners on the furniture. Also avoid exposing the furniture to large changes in temperature and humidity.

Contact a furniture restorer if the coating or wood gets damaged, as it can get worse if not tended to.